

PILOT OPTIONS

DIAL THERMOMETER

Any Spence Temperature Pilot can be equipped with a Dial Thermometer. Pilots with Dial Thermometers are available in the 20-120°F, 70-170°F, 120-220°F and 170-270°F ranges.



DIAL THERMOMETER

PILOT OPTIONS



ADJUSTMENT INDICATOR

ADJUSTMENT INDICATOR

An Adjustment Indicator is a definite convenience where frequent changes in set point are required. Indexed scale makes it easy to return to any previous operating point.

SPRING CHAMBER

Spence Pressure Pilots can be provided with an enclosed spring chamber.

